

PORODO
LIFESTYLE



Porodo Lifestyle
Metal Desk Fan

SKU: PD-LFST043

Table of Contents

Package Contents	2
Schematic View	2
Specifications	2
Instructions for Use	3
Making Adjustments	3
Warranty	4
Contact Us	4

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.


Package Contents

- 1. Desk Fan
- 2. Cable
- 3. Hexagonal Wrench



Schematic View

- 1. Rear Protective Mesh Cover
- 2. Fan Blades
- 3. Motor Component
- 4. Switch
- 5. Status Indicator
- 6. Type-C Port
- 7. Arm Assembly
- 8. Base
- 9. Non-slip Mat
- 10. Front Protective Net
- 11. Adjustment Screws



Specifications


Battery Capacity	2000mAh
Recharge Time	2H
Working Time	2H (Level 3), 4H (Level 2), 6H (Level 1)
Voltage	DC 5V
Rated Power	4W
Speed Levels	3
Height Adjustment	295-175mm
Gross Weight	1kg
Dimension	144×144×175-295 mm
Material	Metal

Instructions for Use

- 1.** Insert one end of the Type-C power supply cable into a USB-A charging port with an output voltage of 5V (such as the USB-A port on the computer). Insert the other end into the Type-C power supply port located on the back of the device.
- 2.** Upon first use, if the power supply is functioning correctly, the working status indicator will blink red, indicating that the built-in battery is charging.
- 3.** Gently press the power button to start the fan in the first speed setting, and the working status indicator will light up. Press the button again to cycle through the speed settings (3-2-1), repeating the sequence: Off-3-2-1.
- 4.** When the fan is operating while connected to a power source, the working status indicator will display both red and green lights. The green light will remain steady, while the red light will flash.

Making Adjustments

To adjust the tension of the alloy support arm, remove the hexagonal wrench from the non-slip pad and insert it into the hexagonal screw hole. Turn clockwise to tighten and counterclockwise to loosen.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**