

**PORODO**



**Porodo**

## **10000mAh Power Bank with Integrated Cables**

SKU: PD-PBFCH057



# Table of Contents

|                      |   |
|----------------------|---|
| Features             | 2 |
| Specifications       | 2 |
| Dimensions           | 3 |
| Instructions for Use | 3 |
| Warranty             | 4 |
| Contact Us           | 4 |

## Features

1. The power bank is equipped with a digital display that shows real-time charging status and battery levels.
2. It can charge batteries from 0 % to 60 % in just 35 minutes, making it ideal for quick top-ups.
3. This power bank has the capability to charge two devices simultaneously, offering greater convenience.
4. Delivers a substantial output of 22.5 watts, suitable for efficiently charging compatible devices.

## Specifications

|                              |  |
|------------------------------|--|
| Battery                      | 10000mAh, 37Wh, 3.7V                     |
| USB-C Input                  | 5V/2.6A, 9V/2A, 12V/1.5A, 18W            |
| USB-C Output                 | 5V/3A, 9V/2.22A, 12V,1.67A, 20W          |
| USB-A Output                 | 5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A, 22.5W |
| <b>Built-In Cable Output</b> |  |
| USB-C Output                 | 5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A, 22.5W |
| Lightning Output             | 5V/2.4A                                  |
| Multi-Port Output            | 5V/3A (Max)                              |
| Size                         | 18×69×147.5mm                            |
| Operating Temperature        | -10°C to 60°C                            |

## Dimensions



## Instructions for Use

### **A. Button Function**

1. A short press activates the digital display, showing the remaining power.
2. Double-click the button to turn off the power output.

### **B. Charging the Power Bank**

The power bank is equipped with a Type-C input. Charge it using the included USB-A to USB-C cable by connecting it to a power source. The digital display will indicate the charging progress, and a full charge is signified when it reaches 100 %. Please disconnect the power bank once fully charged.

### **C. Charging Your Mobile Devices**

To charge your mobile device, connect it to the power bank using the available USB outputs and the built-in USB cables. Note: Different brands or devices may require different cables than those provided. Charging two devices simultaneously may result in slower charging speeds.

### **D. Warning**

If the power bank overheats, immediately disconnect it from the power source or your device and allow it to cool down before further use.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**